

	FS1, Flow Sensor	
V2.1	24V p1 GND	V0.1
	FS2, Flow Sensor	
V2.2	24V p1 GND	V0.2
	FS3, Flow Sensor	
V2.3	24V p1 GND	V0.3
	FS4, Flow Sensor	
V2.4	24V p1 GND	V0.4
	FS5, Flow Sensor	
V2.5	24V p1 GND	V0.5
	FS6, Flow Sensor	
V2.6	24V p1 GND	V0.6
	FS7, Flow Sensor	
V2.7	24V p1 GND	V0.7
	FS8, Flow Sensor	
V2.8	24V p1 GND	V0.8
	FS9, Flow Sensor	
V2.9	24V p1 GND	V0.9
	FS10, Flow Sensor	
V2.10	24V p1 GND	V0.10
	FS11, Flow Sensor	
V2.11	24V p1 GND	V0.11
	FS12, Flow Sensor	
V2.12	24V p1 GND	V0.12
	FS13, Flow Sensor	
V2.13	24V p1 GND	V0.13
	FS14, Flow Sensor	
V2.14	24V p1 GND	V0.14
	FS15, Flow Sensor	
V2.15	24V p1 GND	V0.15
	FS16, Flow Sensor	
V2.16	24V p1 GND	V0.16
	FS17, Flow Sensor	
V2.17	24V p1 GND	V0.17